


KEILHAUER

Tool Required

1/8" Hex Allen Key
1/4" Hex Allen Key

#14 Wrench




Hardware Included

Phillips head screw driver


#14 x 1" Wood screw (x3)

3/8" Lock Nut (x6)


3/8-16 x 1" Socket head screw (x6)




GSD Bench Ganging Assembly Instructions




Slide a support under the gang side of the bench. Using the 1/8" hex key, remove the bench pod from the channel with 5/16 - 18 x 1 1/4" button head cap screw (x6).




Using the Phillips head screw driver, remove the transport leg by removing the #14 x 1" wood screw (x3).



Using a #14 wrench and 1/4" hex key, fasten the ganging leg to the bench channels with 3/8 - 16 x 1" socket head screw (x6) and 3/8" lock nut (x6).



Remove the support from under each channel. Using the 1/8" hex key, reattach the bench pod to the channel (x2) with 5/16 - 18 x 1 1/4" button head cap screw (x6).



Place the assembled bench into its final position.

KEILHAUER

Tool Required

1/8" Hex Allen Key
1/4" Hex Allen Key

#14 Wrench



Hardware Included


5/16-18 x 1 1/4"
Button head cap screw
(x6)

3/8"
Lock Nut
(x2)


3/8-16 x 1"
Socket head screw
(x2)




GSD Corner Bench Assembly Instructions



Using a #14 wrench and 1/4" hex key, fasten the channel (x2) to each other with 3/8 - 16 x 1" socket head screw (x2) and 3/8" lock nut (x2).



Using the 1/8" hex key, fasten the corner bench pod to the channel (x2) with 5/16 - 18 x 1 1/4" button head cap screw (x6).



Place the assembled bench into its final position.