

Operating Instructions ■

Impress® Ultra Task Chair

Back Tilt Operation

December 2012




Figure 1

1. Sit in the chair, then pull-out and push in the rear release lever to familiarize yourself with the movement of this lever (Figure 1 & Detail A).

Note: The chair is equipped with an anti-kick release, back-tilt lock. The release lever must be pulled out before leaning back to tilt chair back. It may take more than one time of leaning back forcefully, to get the back to release.

2. With the release lever pulled out, lean back into the backrest with force until you hear the click of the anti-kick feature releasing the back-tilt lock. Once the click is heard, the back tilt adjustability has been enabled. Move the back to the desired location, then press the release lever back in to set (Figure 1 & Detail A).

Note: Tilt tension is set to high for safety, so the operator of the chair must lean back with more force to release the back-tilt lock.



Assemble units as described herein only. To do otherwise may result in instability. All screws, nuts and bolts must be tightened securely and must be checked periodically after assembly. Failure to assemble properly, or to secure parts may result in assembly failure and personal injury.