

Assembly Instructions ■

Vertical Cable Manager

June 2019

Required Tools

- Cordless Power Drill
- Screwdriver

Vertical Cable Manager Installation

Note: If the Vertical Cable Manager will mount to the underside of the tabletop, proceed to "Tabletop Mounted Cable Manager" instructions below. If the Cable Manager will mount to the underside of the wire trough, proceed to "Wire Trough Mounted Cable Manager" instructions below.

Tabletop Mounted Cable Manager

1. Position the top mounting plate underneath the back, non-user side of the tabletop at the desired location. Assume that the power cords can be routed easily to the mounting plate and to a power source (Figure 1).
2. Using the top mounting plate as a template underneath the table, align the unit straight, and $\frac{1}{4}$ " back from the table edge, then mark the two mounting hole locations and move the plate away (Figure 1).
3. Carefully bore a $\frac{3}{32}$ " pilot hole at the center of each marked location, underneath the tabletop using a cordless power drill. Take care to not drill too deep, piercing the table top (Figure 1).
4. Align the mounting holes of the top mounting plate with the pre-drilled holes underneath the tabletop. Secure the mounting plate to the table using two #9 x 1" flat head screws. Take care to not over tighten (Figure 2).
5. Proceed to page 2 for "Vertical Cable Manager Installation" instructions.

Wire Trough Mounted Cable Manager

Note: Two different size access holes are provided on the wire trough. The smaller hole is used to hold the top mounting plate to the trough while the larger hole is available to feed cables through the trough.

1. Assume that the power cords to use the vertical cable manager can easily be routed to the chosen location for the top mounting bracket (Figure 3).
2. Position the top mounting plate connector end through the wire trough at the smaller access hole location in the wire trough, allowing the connector end to protrude down through the hole as illustrated (Figure 3 & Detail A).




Figure 1




Figure 2





Figure 3



Detail A - Top Mounting Plate in Wire Trough



Assemble units as described herein only. To do otherwise may result in instability. All screws, nuts and bolts must be tightened securely and must be checked periodically after assembly. Failure to assemble properly, or to secure parts may result in assembly failure and personal injury.



Furnishing Knowledge®

Vertical Cable Manager

Assembly Instructions



Assemble units as described herein only. To do otherwise may result in instability. All screws, nuts and bolts must be tightened securely and must be checked periodically after assembly. Failure to assemble properly, or to secure parts may result in assembly failure and personal injury.

Vertical Cable Manager Installation

1. Position one cable link assembly under the top mounting plate. Orient the link assembly so that the power cord from the control box can be easily routed to the link wings. Snap the connector end of the link assembly into the connector hole of the mounting plate (Figure 4).

2. Install a "magnet cable link section" to the bottom end of the previously connected first cable link assembly. To do so, orient the magnet section such that the link wing openings match the first link assembly above. Snap the connector of the magnet section into the receiving end of the first cable link assembly.

Note: To mount the magnet cable link section in a custom location, simply pull apart any connector links where desired, and reconfigure the magnet location.

3. Orient a second cable link assembly under the first cable link assembly (and/or under the magnet section) such that the link wing openings match the link assembly above. Snap the connector of the second section into the receiving end of the link assembly above it (Figure 5 & Detail B).

4. Place the anchor at the desired location on the floor (Figure 5).

5. Take the end of the vertical cable manager assembly and snap the anchor into it (Figure 5).

6. Working from the top of the vertical cable manager assembly and down, insert the power cords into each link by pressing the cords in, between the link wings. Once the desired amount of cords have been inserted, slide cable down through the link assembly (Figure 6).





Figure 4



Detail B - Magnet Cable Link Section




Figure 5




Figure 6