


# FLUX OPEN PLAN

## HOW TO ATTACH A SUSPENDED STORAGE UNIT

### Recommended Tools





### Hardware Needed



#8 x 3/4" PHP Screws

Failure to comply with installation instructions will compromise the safety, durability and performance of this product, which may risk injury to the user of this product and/or diminish the product life cycle. Jasper Group assumes no liability in these instances.



1. Align the boring template with the approach edge and side of the worksurface
2. Bore six 1/8" x 1/2" deep holes in accordance with the template provided in the underside of the worksurface, then insert #8 x 3/4" screws approximately halfway into the surface (Figure 1)
3. Slide the notches in the top of the unit onto the partially inserted screws as shown (Figure 2)
4. Tighten all screws to secure the storage unit tightly (Figure 3)

